










## Portable Fire Extinguishers / 手提式滅火器

Which fire extinguisher to use / 應用在不同火源的區別					
Class of Fire Risk 火源的類別		Water 水劑	Foam 泡劑	CO2 二氧化碳	Powder 乾粉劑
Class A : Paper, Wood and Textile 普通火源 – 紙、木、布等					
Class B : Flammable Liquids 易燃液體					
Class C : Flammable Gases 易燃氣體:					
Electrical Hazards 電器用具					
Vehicle Protection 氣車保護					
Instructions 應用方法		 The nozzle toward the base of the fire 直接噴向火源底 部	 Let the foam fully cover the fire 使泡沫從上而下覆 蓋火源	 The nozzle toward the base of the fire 盡量向火源底部 噴射	 The nozzle toward the base of the fire 直接噴向火源底 部